

Label is feeding out but is blank

If you first label format feeds out of the printer but is blank check the font being used.

Bartender Ultralite defaults to “Kroy Sans Serif”.

This is a printer font. If this is not stored in the printers memory the label will be blank.

Change the font used to a True Type Font.

Double click on the font.

In the edit font box click on “Font” in the left side ladder list.

From the list of available fonts swop to a true type font and click Close.

Please note you may need to change the size of text.

