

**Cleaning tools and methods to maintain your printer.**

1. Please use one of following materials to clean the printer.

- Cotton swab
- Lint-free cloth
- Vacuum
- 100% ethanol / isopropanol cleaning fluid (or industry alcohol)

2. The cleaning process is described as following

<b>Printer Part</b>	<b>Method</b>	<b>Interval</b>
<b>Print Head</b>	1. Always turn off the printer before cleaning the print head. 2. Allow the printhead to cool for a minimum of one minute. 3. Use a cotton swab and 100% ethanol or isopropanol to clean the print head surface.	Clean the print head when changing a new label roll or as needed.
<b>Platen Roller</b>	1. Turn the power off. 2. Rotate the platen roller and wipe it thoroughly with 100% ethanol or isopropanol and a cotton swab, or lint-free cloth.	Clean the platen roller when changing a new label roll or as needed.
<b>Peel Roller</b>	1. Turn the power off. 2. Rotate the Peel-off roller and wipe it thoroughly with 100% ethanol or isopropanol and a cotton swab, or lint-free cloth.	Clean the peel roller when changing a new label roll or as needed.
<b>Tear Bar/Peel Bar</b>	Use the lint-free cloth with 100% ethanol or isopropanol to wipe clean.	As needed.
<b>Sensor</b>	Compressed air or vacuum	Monthly.
<b>Exterior</b>	Wipe it with water-dampened cloth	As needed.
<b>Interior</b>	Brush or vacuum	As needed.

**Note:**

- Do not touch the print head by hand. If you touch it carelessly, please clean as above.
- It's industry alcohol. Please do not use regular alcohol, which may damage the print head.
- You may have to clean the supply sensors more often if you frequently receive error messages.